



Pants Box Dress Fold

Folding instruction

- Each garment folded as illustrated. Garments must be unbuttoned.
- Each garment packed in a polybag with size print.
- Packed in assortment as stated on ordersheets or unassorted.



Carton instruction

- Carton size should fit the folded garment size exactly. Not smaller and not bigger. Please see specifications for carton quality in supplier manual.
- Every 2nd garment should be packed conversely.
- Please see illustration.