

Hangers

Blazer – pants - suits – jackets

Upper-body wear:


Quality of hanger:

Should follow Digel Hanger for style/shape/hand feel

Make sure hook is firmly attached to the plastic

Logo: use correct logo according to brand, but not framed as Digel.

Size: Different (look below)



For blazers:

Hanger size 42cm up to blazer size 50

Hanger size 46cm from blazer size 52 and up

No cross bar as picture.

For suits (blazer & pants):

Hanger size 42cm up to suit size 50

Hanger size 46cm from suit size 52 and up

Same as for blazers just incl. cross bar with black foam and plastic pin

For jackets (not blazers):

Hanger size 46cm for all jacket sizes

Incl. cross bar without foam

Lower-body wear:

All separate suit pants should be delivered on hanger with below details.

Note: important that they are secured with plastic pin padded with black foam in order to make marks on the pants.

