


Label: LINDBERGH	Date: 25/09/2019 Modification date: 25 March 2025 2:34 pm	
Description: Label instruction for hats	Labels instruc. No.: LBA-1000	Design: AKR/JTG/TMA

Technical sketch

Hangtag LBA-900A



Hangtag LBA-900A placement

Priority placement through woven label or fix the tag with a safety pin

Priority 1



Priority 2



Plastic hanger

Place plastic hanger in top of hat



Care label 051

Care label should be sew inside hood.




Hangtag LBA-900A Sticker on backside.

With style no. and colour.



STICKER for salesmand sample

Follow instruction no. :
007 salesman sticker



Please place sticker
on the backside
of hangtag within
placement marks

Suppliermade sticker:

BARCODE for production



Barcode
Placement
(for production
Only)
Place price
Sticker at fixing
Points.

Suppliermade sticker: